

Certificate of Analysis

For Research Use Only Not for Human or Animal Consumption

KPL SureBlue[™] TMB Microwell Peroxidase Substrate (1-Component)

PART CODE: 5120-0078 (52-00-04) 10696123 5000 mL DESCRIPTION: This liquid substrate system develops a dark blue soluble product when reacted with horseradish peroxidase labeled conjugates in microwell plates or tubes. It is not recommended for membrane or immunohistochemical staining assays. FORM/STORAGE: Liquid. Store refrigerated at 2 - 8°C. CONTENT: The one component system is supplied as 5000 mL bottles, from bulk Lot No. 10696123. The KPL SureBlue TM TMB Microwell Peroxidase Substrate (1-Component) contains 3,3'5,5'- tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide is 0.01%. STABILITY: Product is stable for three years from date of manufacture when stored properly. DATE OF MANUFACTURE: 28 MAR 2024 RECOMMENDED REDISPENSING KPL SureBlue TM TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: • Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. • Never pipete directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue TM TMB to the primary container. • Avoid prolonged exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. • HOPE and LDPE bottles sh		
peroxidase labeled conjugates in microwell plates or tubes. It is not recommended for membrane or immunohistochemical staining assays. FORWSTORAGE: Liquid. Store refrigerated at 2 - 8°C. CONTENT: The one component system is supplied as 5000 mL bottles, from bulk Lot No. 10696123. The KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) contains 3.3', 5, 5'. Letramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide is 0.01%. STABILITY: Product is stable for three years from date of manufacture when stored properly. DATE OF MANUFACTURE: 28 MAR 2024 RECOMMENDED REDISTRY KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: • Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. • Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. • Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refiberes into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate efformance. • HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. • Redispense into amber Nalgene HDPE or LDPE bottles ONLY. D	LOT NUMBER:	10696123
 CONTENT: The one component system is supplied as 5000 mL bottles, from bulk Lot No. 10696123. The KPL SureBlue[™] TMB Microwell Peroxidase Substrate (1-Component) contains 3.3:5.5' tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide is 0.01%. STABILITY: Product is stable for three years from date of manufacture when stored properly. DATE OF MANUFACTURE: 28 MAR 2024 RECOMMENDED KPL SureBlue[™] TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue[™] TMB to the primary container. Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. Redispense substrate using Cole-Parmer C-Flex tubing and on or reuse tubing. Avoid redispensing with all other tubings sucluding silicone, latex, and Tygon. Gravity fill or the use of a peristaltic pump is advised. Avoid substrate contact with any metallic surfaces. For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167. 	DESCRIPTION:	peroxidase labeled conjugates in microwell plates or tubes. It is not recommended for membrane
KPL SureBlue™ TMB [®] Microwell Peroxidase Substrate (1-Component) contains 3,3',5,5'- tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide is 0.01%. STABILITY: Product is stable for three years from date of manufacture when stored properly. DATE OF MANUFACTURE: 28 MAR 2024 RECOMMENDED REDISPENSING KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon. Gravity fill or the use of a peristatic pump is advised. Avoid substrate contact with any metallic surfaces. For further details concerning the redispensing of	FORM/STORAGE:	Liquid. Store refrigerated at 2 - 8°C.
DATE OF MANUFACTURE: 28 MAR 2024 RECOMMENDED REDISPENSING KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: • Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. • Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. • Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. • Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. • HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. • Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon. • Gravity fill or the use of a peristatic pump is advised. • Avoid substrate contact with any metallic surfaces. • For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167.	CONTENT:	KPL SureBlue [™] TMB Microwell Peroxidase Substrate (1-Component) contains 3,3',5,5'- tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide
MANUFACTURE: 28 MAR 2024 RECOMMENDED REDISPENSING KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: • Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours into harmful. • Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. • Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. • Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. • HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. • Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon. • Gravity fill or the use of a peristaltic pump is advised. • Avoid substrate contact with any metallic surfaces. • For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167.	STABILITY:	Product is stable for three years from date of manufacture when stored properly.
 REDISPENSING to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlueTM TMB to the primary container. Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon. Gravity fill or the use of a peristaltic pump is advised. Avoid substrate contact with any metallic surfaces. For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167. 		28 MAR 2024
Approval: Contraction of APR 2024		 to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product: Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful. Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container. Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color. Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance. HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended. Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon. Gravity fill or the use of a peristaltic pump is advised. Avoid substrate contact with any metallic surfaces. For further details concerning the redispensing of this product, please contact the Technical
	Approval:	orker 09 APR 2024
	QA Verified By	

www.seracare.com