

## **Certificate of Analysis**

For Research Use Only Not for Human or Animal Consumption

## KPL SureBlue<sup>™</sup> TMB Microwell Peroxidase Substrate (1-Component)

PART CODE: LOT NUMBER: SIZE DESCRIPTION:	<ul> <li>5120-0076 (52-00-02)</li> <li>10633630</li> <li>4 x 100 mL</li> <li>This liquid substrate system develops a dark blue soluble product when reacted with horseradish peroxidase labeled conjugates in microwell plates or tubes. It is not recommended for membrane</li> </ul>
	or immunohistochemical staining assays.
FORM/STORAGE:	Liquid. Store refrigerated at 2 - 8°C.
CONTENT:	The one component system is supplied as 100 mL bottles, Lot No. <b>10624406</b> manufactured on <b>15 JUN 2022</b> . The KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) contains 3,3',5,5'-tetramethyl-benzidine in an acidic buffer. The concentration of the Hydrogen Peroxide is 0.01%.
STABILITY:	Product is stable for three years from date of manufacture when stored properly.
RECOMMENDED REDISPENSING	<ul> <li>KPL SureBlue™ TMB Microwell Peroxidase Substrate (1-Component) is extremely sensitive to certain handling and storage conditions. The following suggestions are provided to ensure success when redispensing this product:</li> <li>Avoid prolonged exposure to light air or extreme temperatures; however, exposure to indirect laboratory lighting for 24 hours is not harmful.</li> <li>Never pipette directly from bottle. Pour out needed amount into a plastic reservoir. Do not return excess KPL SureBlue™ TMB to the primary container.</li> <li>Avoid exposure to silica-based materials including borosilicate glass, metals, bacterial contamination or other oxidizing agents. Do not refilter as this may destabilize the dye complex and result in the development of background color.</li> <li>Redispense into amber Nalgene HDPE or LDPE bottles ONLY. Do not redispense into glass bottles as this may compromise substrate performance.</li> <li>HDPE and LDPE bottles should be utilized as they are received directly from the manufacturer; washing of bottles is not recommended.</li> <li>Redispense substrate using Cole-Parmer C-Flex tubing and do not reuse tubing. Avoid redispensing with all other tubings including silicone, latex, and Tygon.</li> <li>Gravity fill or the use of a peristaltic pump is advised.</li> <li>Avoid substrate contact with any metallic surfaces.</li> <li>For further details concerning the redispensing of this product, please contact the Technical Service Dept. at 800-638-3167.</li> </ul>

Approval:

Muraleiserei	18 AUG 2022
QA Verified By	Date